



User Manual

Chakra Activator



Please read the manual before using the tools.

Version 5.5
Updated July 10, 2026

1. General Notes

1.1 Product Feature and Intend Use

Chakra Activator is a powerful energy-balancing device that aligns and revitalizes your chakras using **sound, color light therapy, magnetic fields, and plasma bursts**. It enhances emotional stability, boosts vitality, and promotes deep relaxation.

It also features **element activation technology**, transforming water, oils, and crystals into high-energy substances for better absorption and well-being.

Your **Chakra Activator** is tested for peak performance, ensuring effortless energy balance and holistic wellness in your daily life.

1.2 Product Details

- Light and sound frequency adjustment equipment for therapy and healing.
- Use electronic circuits.
- Output uses LED RGB, LED UV-C, PCB Bifilar Coil and PCB Scalar Coil.

1.3 Safety Warnings

- Check all accessories upon unboxing.
- Read and follow all safety instructions in the manual.
- Do not use near water or in wet areas.
- Do not open the cover unless you are a professional technician.
- Avoid placing the device near heat sources such as stoves.
- Only use the power voltage specified in the manual.

1.4 Warranty

- Your Chakra Activator includes a one-year warranty from the date of purchase.
- If you experience any issues, contact customer support immediately.

- The warranty does not cover damage due to:
 - Misuse or neglect
 - Unauthorized modifications or disassembly
 - Customs/import fees or indirect damage
 - If repairs are needed due to misuse, all costs (including shipping) will be the user's responsibility

1.5 Important Precautions

- Do not use the device if it appears damaged. Contact customer support.
- Charge for at least 1 and half hours before the first use.
- Do not disassemble or modify the device.
- Keep dry – avoid rain, high humidity, heat, and dust.

1.6 Maintenance

- If the device has not been used for a while, charge it for at least 2 hours before using it.
- Always keep the device clean to ensure optimal performance.
- Use soft, dry cloth or a water-based glass cleaner for cleaning.
- Avoid using harsh chemicals or abrasive materials on the device.
- Store the device in a dry place and avoid direct sunlight.
- If you encounter any issues, please contact our customer service team.

1.7 Product Includes

- Chakra Activator
- USB Type-C cable




2. Technical Data

2.1 Specifications

Product name:	Chakra Activator
Color:	White / Gold
Material:	ABS + Glass
Input:	5 V DC / 1.0A
Charging Interface:	USB Type-C
Battery Type:	Lithium polymer 3.7 V/ 1.0A
Light LED:	RGBUV 18W
Red Wavelength:	220-225nm
Green Wavelength:	520-525nm
Blue Wavelength:	460-465nm
UV Wavelength:	400-430nm
Frequency Range:	998Hz – 171 kHz
Length:	90.24 mm
Width:	90.24 mm
Height:	26.35 mm
Weight:	91 g

2.2 Overview and Function



2.3 Charging Setup

1. To charge the **Chakra Activator**, connect the USB-C cable to the device and a power adapter, then plug it into a power source.
2. Charging takes about 1 and half hours from an empty battery and lasts over 4 hours. (*Battery capacity can be reduced.*)
3. When the battery is low, the red LED will flash to warn you of a low battery.
4. The red light will blink while the battery is charging and will stop once the battery is fully charged.



 To protect the battery life span, please don't overcharge it.

3. Operation



Volume Adjustment



Turn on/off button and Chakra Program Mode

1. To turn on the device, press the button once to turn it on. The device will start using its basic functions.
2. There is a volume button to increase and decrease the sound.
3. To turn off the device, press the button twice in a double-pressing manner. The device will stop working immediately.


Advance Setting

1. Press the button once to turn on the device, the white LED will flash, this mode is called Element Activator mode.



- Place a glass of water, essential oils, or cosmetics on the Chakra Activator to restructure them using pulsed color light and magnetic resonance.
- The Element Activator clears negative energetic imprints and infuses each substance with life-enhancing frequencies, supporting better hydration, improved nutrient absorption, and increased cellular vitality.
- Ideal for water, remedies, essential oils, and skincare products.

2. Pressing the button again will allow it to enter advanced mode, with 7 lights and 7 sounds, arranged in the following colors: red, orange, yellow, green, blue, indigo, and purple.



Element Activator and Chakra Mode

- Program 1: Root Chakra (Red Color)
- Program 2: Sacral Chakra (Orange Color)
- Program 3: Solar Plexus Chakra (Yellow Color)
- Program 4: Heart Chakra (Green Color)
- Program 5: Throat Chakra (Blue Color)
- Program 6: Third Eye Chakra (Indigo Color)
- Program 7: Crown Chakra (Purple Color)

3. If pressed once more, the device will automatically loop all 7 Chakra points.
4. If you press it again, it will return to Element Activator mode.
5. After turning it on, the device will automatically shut down after 45 minutes per usage.

Disclaimer

Light Mandalas products are designed as energy support tools for relaxation, stress management, and well-being. They are not medical devices and do not replace professional medical treatment or advice.

Any experiences or testimonials shared regarding the use of our products reflect individual responses and are not guaranteed outcomes. Since personal energy and emotional states vary, users may experience different effects, including heightened sensitivity or discomfort. By using our products, you acknowledge that all outcomes are your sole responsibility.

Light Mandalas Co., Ltd. (Thailand) is not liable for any unintended effects, discomfort, or injuries that may arise from product use. If you have any medical concerns, please consult a healthcare professional before using our products.

For any questions, please reach out to us for further support.

Light Mandalas Co., Ltd. (Thailand Headquarters):

- Light Mandalas Website: www.light-mandalas.com
- Email: info@light-mandalas.com
- Tel: 093 132 9333, 091 628 9936
- Instagram: @mandalawave9
- YouTube Channel: Light Mandalas Official
- TikTok: Light Mandalas
- WeChat: Light Mandalas 光之曼陀罗
- Technical Support Email: cservice@light-mandalas.com