

User Manual

Mandala Violet Shield




Please read the manual before using the tools.

Version 1.0

Table of Contents

1	General Notes.....	2
1.1	Product Feature and Intend Use	2
1.2	Warning	2
1.3	Warranty	2
1.4	Precautions	3
1.5	Maintenance	3
1.6	Product Include	4
2	Technical Data	5
2.1	Specifications	5
2.2	Overview and Function.....	6
3	Installation and Operation Instruction	7
3.1	Setup	7
3.2	Charging Setup	8
4	Fault Diagnosis.....	10



1 General Notes

1.1 Product Feature and Intend Use

Thank you for using Light Mandalas Product. Mandala Violet Shield has been in good condition before leaving factory.

Mandala Violet Shield is an Ultraviolet-C disinfection equipment that works on the highest frequency possible and has been shown to be one of the safest Ultraviolets for the human body. Despite the fact that we do not encourage looking at it directly, it is a short frequency/shortwave that does not penetrate deep into the skin to cause injury and does not pass beyond the liquid in the eyes. As a result, it is one of the safest wave ranges.

Mandala Violet Shield can be used to disinfect the space both emotionally and physically, as well as a room disinfectant. It can also be connected to a tablet via Bluetooth, and we have all of the libraries for healing frequencies to inhibit negative energies. The library is also scannable with Mandalas Scan, so we can use it and transfer it to this device through Bluetooth. It also includes an audio-triggered mode that we can use sound healing files to trigger, so there are actual audio files and MP3 files with extremely sophisticated sounds that are striking whether the libraries of sounds that have certain functions singing in the physiology as well as energetics.

1.2 Warning

This product is in perfect condition before delivery, please check all accessory when unpacking the unit.

Pay close attention to each safety REMARK and WARNING statement in the manual. This manual contains important operation information.

1.3 Warranty

Each single product passes through a quality process. Nevertheless, if failures occur, contact the customer service at once. The product is under 1 year warranty effectively according to the delivery date stated on the warranty card.

Warranty does not apply to damages, which result from misuse or neglect. The warranty also expires if you dismantle the product or failed to provide the warranty card. The manufacturer is not liable for consequential damage or in case of a non-intended use of the product.

If a failure occurs during the warranty period, the product will be replaced or repaired. The manufacturer reserves the right to exchange components of the product instead of repairing it. If the failure results from misuse or neglect, the user must pay for all cost that may occur. The freight cost and other costs will be depending on which Term & Conditions criteria the product falls into. **Import tax and Customs clearance duty cost is not included in the term of warranty.** In that case, you may ask for an estimated cost beforehand.

1.4 Precautions

1. Please check the device for damage during shipping. Do not use the device if any damage is discovered. If the device is damaged, please contact the dealer or Light Mandalas immediately
2. Please Confirm the product you have received are in correct voltage and frequency for your country.
3. Mandala Violet Shield needs to be charged at least 2 hours prior to first use.
4. Do not disassemble or modify the device in any case.
5. Do not use the device outdoors when it rains
6. Places the device in a well-ventilated area.
7. Keep dry and avoid excessive humidity, heat or dust.
8. Do not place the device closer than 2 feet from combustible object.

1.5 Maintenance

1. If the device has not been used for a long time, please charge for 2 hours before use.
2. Clean with soft cloth, humid tissue moistened with water or a water-based glass cleaner.
3. In order to guarantee the fixture works properly, it is essential to keep it clean.

1.6 Product Include

1. Mandala Violet Shield x1



2 Technical Data

2.1 Specifications

Product name:	Mandala Violet Shield
Color:	Black
Material:	Quartz Tube + Stainless Steel + Plastic ABS + Resin
Input Voltage:	DC 5V / 2A
Charging Interface:	Micro USB
Battery Type:	Built-in 3.7V 2000mAh Polymer Battery
UV Wave Length:	185-254nm
frequency:	0 - 40MHz
Bluetooth:	HC-05 Audio Bluetooth
Length:	47 mm.
Width:	36.20 mm.
Height:	219 mm.
Weight:	165 g.

2.2 Overview and Function

Bottom View



- 1. **ON/OFF Button**
- 2. **Audio**
- 3. **USB Charging**

Slide to switch off and switch on the device
Plug in speakers to play sound.
Plug in the USB cable to charge here.

Front View



Side View



3 Installation and Operation Instruction

3.1 Setup

1. Switch on Mandala Violet Shield



2. Please insert the headset head to the Mandala Violet Shield Socket to play "Audio Mode".

(How to active Audio Mode, we have explained in Mandala Star Application User Manual.)



3.2 Charging Setup

1. To charge Mandala Violet Shield, plug in the **USB Type-C Cable** to the device charging port and connect the other end to the provided **Charging Adapter** or powered up computer. Connect the **Charging Adapter** to the power supply and turn it on.



2. The **Battery Charging Status Light** will be changed from red to green when it is charged fully.



RED – Charging

GREEN – Fully Charged

3. The charging process takes about 2 hours if starting with a fully drained battery and provides over 6 hours of battery life.



In order to protect the battery life span, please don't overcharge the battery.



4 Fault Diagnosis

Failures	Remedies
Device cannot turn on	<ul style="list-style-type: none">• device battery life is low. Please charge the device.• Plug in the charger. If it can be used during charging, that means the device need to be charged.
Cannot connect to tablet	<ol style="list-style-type: none">a) Check the application setting.b) Turn off the device, and turn off tablet Bluetooth then try to turn them on again.c) Plug in the charger. If it can be used during charging, that means the Bluetooth battery need to be charged.

Disclaimer

All content found on the Light-mandalas.com Website, Facebook Page, YouTube, including: text, images, video, audio, or other formats are intended for informational, educational and research purposes only and neither Light Mandalas Co. Ltd. nor the publishers of this content take responsibility for possible health consequences of any person or persons reading or following the information in this educational content and is not intended to be a substitute for professional medical advice, diagnosis, treatment or cure. Always seek the advice of your physician or other qualified health professionals with any questions you may have regarding a medical condition.

“No claims other than stress detection and stress reduction may be made”

Light Mandalas products are to be used as a Heart Rate Variability Biofeedback system and Light, Color and Sound therapy, designed for stress detection and stress reduction only. The devices do not evaluate any issue other than stress. Stress can come from many sources; this system uses light and color and sound therapies to reduce stress. Remember, there has never been any reported side effects using light, color, and sound therapy anywhere in the world and throughout time.

Notes on the practices of low-level laser therapy (LLLT) and Biofeedback

Low-level laser therapy (LLLT) is considered investigational by the FDA, and no medical claims of cures are permitted in the US; at this time however, low-level lasers are defined within the scope of complimentary medical practices such as physiotherapy, aesthetic, Traditional Chinese Medicine, and acupuncture, etc.

The FDA does not regulate Bio resonance tools, but they do regulate biofeedback tools and some Bio resonance tools are registered under this category.

*It is a legal requirement at this time that the user does not make any medical claims of diagnosis or cure.

Precaution

Light Mandalas products are working on energetic level. The standard benefit is energy clearance. During the process, your body and mind can be uncomfortable. The symptoms associated with overly rapid clearance of toxins. If those detox symptoms are too strong, you may need to stop using the products. You have to allow the clearance or detox to proceed, and you can start to try the products afterwards. However, if the issues still remain the same, it may need to be completely discontinued for your own safety

*Although UVC is considered the safest of the UV wavelengths please do not place stationary on the bare skin for extended period of time (more than 1 minute) and avoid looking directly into the light source.

Shall there be any inquiry, please contact us for further support.

Light Mandalas Co., Ltd. (Thailand Headquarters):

- **Light Mandalas Website:** www.light-mandalas.com
- **Official:** info@light-mandalas.com
- **Instagram:** [@mandalawave9](https://www.instagram.com/mandalawave9)
- **YouTube Channel:** Light Mandalas Official
- **Technical Support Email:** cservice@light-mandalas.com

Local agents contacts:

- **Japan:** japan@light-mandalas.com
- **Taiwan:** lovelight777888@gmail.com
- **Indonesia:** lightseed2020bali@gmail.com
- **West Malaysia:** lightworker@healingtech.org
- **East Malaysia:** malaysia@light-mandalas.com
- **Hungary:** horesnyibela@light-mandalas.com
- **Switzerland, Germany, Austria, and the Netherlands:** info@light-mandalas.ch
- **France, Spain:** france-spain@light-mandalas.com
- **USA:** usa@light-mandalas.com
- **New Zealand, Australia:** tachyonhealing.nz@gmail.com